

# The AN-80 external antenna

This antenna is designed for Jablotron wireless products which use a frequency of 868 MHz and are equipped with a connector only for use with AN-8x antennas.

If you want to use the AN-80 antenna see the wireless device's manual for detailed instructions.

The active part of the antenna should be installed vertically and it should not be obstructed by any metal objects.


The antenna can only be placed on a non-conducting material.

If the antenna is used in an alarm system, it should be located in the area which is protected by the alarm system.

Note: Do not extend its RF cable.

## **Technical specifications:**

<i>Communication band</i>	868 MHz
<i>Impedance</i>	50 $\Omega$
<i>Cable length</i>	2m



Jablotron Ltd., Pod Skalkou 33  
466 01 Jablonec nad Nisou  
Czech Republic  
Tel.: +420 483 559 911  
fax: +420 483 559 993  
Internet: [www.jablotron.com](http://www.jablotron.com)